# 1130 PATH LIGHT

LED - (1130)



#### Standard Installation















1/8", 5/32", 5/64" Allen Wrench

Waterproof Wire Connectors



IMPORTANT - WEAR GLOVES TO AVOID GETTING FINGERPRINTS ON THIS PRODUCT. MANY TEKA ILLUMINATION PRODUCTS ARE DESIGNED TO NATURALLY PATINA. OILS FROM YOUR SKIN WILL ACCELERATE THIS PROCESS WHERE TOUCHED AND ARE NEARLY IMPOSSIBLE TO REMOVE. THIS PROCESS OCCURS OVER TIME AND IS DETERMINED BY THE INSTALLATION ENVIRONMENT.

### INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY TO PERSONS IMPORTANT SAFETY **INSTRUCTIONS**

#### Lighted fixture is HOT! WARNING - To reduce the risk of FIRE OR INJURY TO PERSONS:

Turn off/unplug and allow to cool before replacing lamp/LED. Fixture gets HOT quickly! Contact only switch/plug when turning on. Do not touch hot lens, guard, or enclosure. Keep fixture away from materials that may burn. Do not operate the luminaire fitting with a missing or damaged shield. Do not touch the source at any time. Use a soft cloth or gloves. Oil from skin may cause damage.

SAVE THESE INSTRUCTIONS

# IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS

- · Product must be installed by a qualified person in a manner consistent with its intended use and in compliance with the National Electrical Code, Canadian Electrical Code, and all Local and Provincial Codes.
- · Follow product label information and instructions.
- · Qualified Personnel with appropriate personal protective equipment must perform all servicing of this product.
- · Before wiring to power supply and during servicing, turn off and lock out power at fuse or circuit breaker before service.
- · The use of accessory equipment not recommended by the manufacturer or installed contrary to instructions may cause an unsafe condition. The use of damaged components may cause an unsafe condition and void product warranty.
- Do not block light emanating from product in whole or part, as this


may cause an unsafe condition.

- · Never operate the fixture with missing or damaged lens. Lens must be cleaned on regular basis.
- · Entire fixture may become extremely hot. Do not touch hot
- · Replace LED assembly only with correct wattage and type of power supply appropriate for LED assembly.
- · All gaskets, o-rings and sealing surfaces must be kept clean during installation and service; failure to do this may cause an unsafe condition and void product warranty.

#### **IMPORTANT LISTINGS AND CERTIFICATIONS**

· Suitable for wet locations

Please refer to the low voltage design guide at www.tekaillumination.com/lvguide before installation for proper wire selection.



# IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE THESE INSTALLATION **INSTRUCTIONS**



40429 Brickvard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900 www.tekaillumination.com • info@tekaillumination.com

RELEASE DATE 08/09/2024 REFERENCE NUMBER INS000957







#### Standard Installation

À


Must install to a suitable enclosure. Recommended for use with Power Pipe™, #20 Surface Mount Adaptor or Pillar Mount Canopy (PMC).



- Mount stem onto suitable enclosure and/or mounting option according to designed lighting plan.
- Recommended for use with power pipe, #20 surface mount adaptor or pillar mount canopy (PMC).




- 2. Secure stem with locknut (included).
- Make watertight connections from remote magnetic transformer to fixture leads using waterproof wire connectors (not included). See wiring diagram.




#### WIRING DIAGRAM

LED - For use with 12VAC LED remote transformer or magnetic transformers only. TEKA Illumination cannot guarantee performance with third party manufacturers' transformers.


# To Replace Components



 Loosen three (3) #8-32 set screws on shade assembly using a 9/64" allen wrench and remove.



- Loosen three (3) #8-32 set screws with a 9/64" allen wrench on heat sink to remove LED board and driver assembly.
- Use a 5/64" allen wrench to remove two (2) #2-56 socket head cap screws on LED board, grasp LED board and gently pull up to expose quick disconnect.
- Disengage LED board and driver assembly Replace with new board and driver assembly.



5. Replace shade. Tighten three (3) #8-32 set screws on shade assembly using a 9/64" allen wrench.

